

Parts list of M1Q-GW6-80

Serial Nr.	Description	Quantity	Serial Nr.	Description	Quantity
1	Safety Mask	1	31	Shank holding Board	1
2	Left Housing	1	32	spring	1
3	Variable Speed Board	1	33	Bearing	1
4	Switch	1	34	Blade Shank	1
5	Pendulum Button	1	35	Blade	1
6	Spring	1	36	Bearing	1
7	Pin	1	37	Supporting Rack	1
8	Parallel Ruler	1	38	Bearing	1
9	Button	2	39	Rotor	1
10	Bottom Base	1	40	Carbon Brush holder Cover	2
11	Angle Adjusting Board	1	41	Carbon Brush	2
12	Bottom Base holding Piece	1	42	Carbon Brush Holder	2
13	Bottom Base holding Board	1	43	Bearing	1
14	Screw	2	44	Stator	1
15	Rubber Circle	1	45	Inductor	2
16	Exhaust Collection	1	46	Pin	1
17	Cable Jacket	1	47	Spring	1
18	Allen Key	1	48	Pin	1
19	Cable	1	49	Pendulum Rack	1
20	Strain Relief	1	50	Safety Needle	1
21	Screw	4	51	Laser Cover	1
22	Lock Spring	1	52	Laser Switch Button	1
23	Washer	1	53	Laser Set	1
24	Idler Pulley	1	54	Screw	2
25	Big Gear	1	55	Screw	5
26	Needle Bearing	1	56	Right Housing	1
27	Balance Board	1	57	Screw	2
28	Pin	4	58	Bottom Base Cover	1
29	Pin	1	59	Screw	6
30	Pendulum Board	1			

